



South Portland, ME

Terminal spec sheet



	Bay 1	Bay 2	Bay 4	Bay 6
Loading	Bottom	Bottom	Bottom	Bottom
Ultra Low Sulfur Heating Oil	✓	✓	✓	✓
Ultra Low Sulfur Diesel (Clear & Dyed)	✓	✓		✓
Gasoline (Regular, Plus, Supreme)	✓	✓		✓

Address:
102 Mechanic St.
South Portland, ME
04106

Hours of operation:
24/7, 365 days a year

Phone: 207.799.3394
Fax: 207.799.0319

Call our Customer Support Team at 1.866.865.8800 or email us at IOCCustomerSupport@irvingoil.com



South Portland, ME

Terminal spec sheet

Driver orientation training

To ensure all lifts are made easily and safely, we offer training for drivers. Here are the steps to take to attend our training:

STEP 1 – Complete our compliance checklist

Please ensure you have the following documents before your orientation training. Each of these documents must be with you during every visit to our terminal.

Trailer requirements:

- Annual visual inspection
- 5 year inspection
- Probe certification
- Annual pressure test, EPA Method 27

Driver requirements:

- Hazard endorsement
- TWIC requirements
- Valid driver's license

Drivers should wear leather work shoes with oil-resistant soles, along with long pants and short sleeves (no striped T-shirts).

STEP 2 – Schedule an appointment

To schedule your driver orientation training, please call the South Portland terminal (207.799.3394) more than 24 hours in advance.

STEP 3 – Attend the training

- The driver orientation training takes about 20 minutes.
- Once new drivers have successfully made three loads supervised by a trained driver, we observe them on the fourth load to ensure compliance.
- To receive an access card, drivers must have three supervised loads, answer an orientation questionnaire, and meet our compliance checklist.



If you have any questions, please contact our Customer Support Team at **1.866.865.8800** or by email at IOCCustomerSupport@irvingoil.com.

Thanks for your business, and we look forward to serving you.